

Portable laser measurement and calibration





Machine tools and CMM The ultimate tool for machine tool and

CMM verification to international standards



Motion systems Unique dynamic performance for high

speed, high resolution investigations



Research and metrology

Traceable measurement for calibration and research laboratories

From the world's leading laser measurement system manufacturer: the XL-80 laser system

Renishaw has been designing, manufacturing and supplying laser interferometer systems for over 20 years. Its ML10 laser system has become a globally recognised standard for accuracy and reliability in use.

The new XL-80 laser system offers greatly increased portability, system accuracy and improved dynamic measurement performance. It is quicker and easier to use, whilst retaining the benefits of a pure interferometry based system; a proven technology that has made Renishaw laser systems the preferred choice of companies worldwide.

XL-80 retains Renishaw's key virtues of accuracy, reliability and durability in day-to-day use, where it really matters.





XL-80 laser (with optional universal shutter) and XC-80 compensator

Increased performance from the XL laser measurement system widens your measurement options. Significantly smaller than existing systems, it delivers improved portability and ease of use, helping your business to stay ahead



XL system components

The basis of the new system is a compact laser head (XL-80) and an independent compensator system (XC-80)





XL-80 laser

The XL-80 laser produces an extremely stable laser beam with a wavelength that is traceable back to national and international standards.

The laser frequency stability is specified as ± 0.05 ppm over 1 year and ± 0.02 ppm over 1 hour. This excellent performance is achieved by dynamic thermal control of the laser tube length to within a few nanometres.

Linear measurement accuracy is an assured ±0.5 ppm over the whole environmental range i.e. from 0 °C - 40 °C (32 °F -104 °F) and 650 mbar - 1150 mbar. Readings are taken at 50 kHz, with a maximum linear measurement speed of 4 m/s and a linear resolution of 1 nm; even at maximum speed.

As the XL system uses interferometry as the basis for all its measurement options (not just linear), you can have confidence in the accuracy of all your measurements. With integrated USB there is no requirement for a separate laser-to-PC interface. The laser also features an auxiliary analogue signal output as standard, with quadrature output a factory option. The same socket also accepts a trigger signal input for data capture synchronisation.

LED status lights, indicating laser status and signal strength, provide back-up to the software's 'on-screen' indicators. Together with a switchable long range mode (40 m - 80 m) and a warm-up time of less than 6 minutes, these features make the XL-80 quick and easy to use.

An external, switch mode power supply ensures 90 V - 264 V flexibility in input voltage.

XL-80 system components

XC-80 compensator and sensors

The XC-80 compensator is a key factor in your XL system's measurement accuracy. Featuring 'intelligent sensors' that process the readings at source, the compensator very accurately measures air temperature, air pressure and relative humidity.



It then modifies the nominal value of the laser wavelength to give a true value, used in displacement calculations, which virtually eliminates any measurement errors resulting from these variations. This can be done automatically, every 7 seconds, as indicated by LED status lights on the XC-80 unit.

Like the XL-80 laser, the compensator is directly connected to your PC via a USB port which, for the XC unit, also supplies power (no separate power supply is required).

Sensor cables are 5 m long and detachable for easy replacement. Multiple cables can be screwed together for extended lengths on longer machines.



The design of the XC-80 and sensors ensures extremely accurate readings over the full range of operating conditions, from units that are built to withstand the daily handling that most systems will receive.

Up to three material temperature sensors can also be attached to the XC-80 compensator to allow linear measurements to be normalised to a standard material temperature of 20 °C.

Both the air and material temperature sensors are 'intelligent'. Integral microprocessors analyse and process the sensors' output before sending digital temperature values to the XC-80 compensator. This offers more secure measurements and is a key reason why the XC-80 is so compact.

The XC-80 weighs only 490 g and together with the XL-80 weighs just over 3 kg (including connecting cables, XL power supply and sensors).

Sensor performance	Range	Accuracy
Material temperature	0 °C - 55 °C	±0.1 °C
Air temperature	0 °C - 40 °C	±0.2 °C
Air pressure	650 mbar - 1150 mbar	±1 mbar
Relative humidity (%)	0% - 95% non-condensing	±6% RH



XL system components

Tripod and stage

Unless you are using a dedicated measurement rig, then you are likely to need a tripod and stage to adjust the laser's position relative to the desired measurement axis. A new universal tripod has been extensively tested to provide a stable adjustable base in a compact, lightweight unit.

The XL tripod stage allows for precise angular rotation and translation of the XL-80 and is designed to be left attached to the laser unit for easy storage and quick set-up.





A 'quick fit/release' mechanism enables rapid and secure fixing to the tripod. For those applications where tripod mounting is not convenient, e.g. for mounting directly on a machine tool table, the stage and laser can also be mounted on most standard magnetic bases, using an optional adapter with M8 thread. Due to careful design, the XL-80 laser and optics can also be placed directly on a granite table (without tripod stage) for co-ordinate measuring machine (CMM) calibration.

The tripod and tripod case together weigh just 6.2 kg, to complement the portability of the rest of the laser system.



LaserXL[™] software maximises your XL system performance and flexibility

Powerful software and clear but extensive support documentation are key to releasing the potential of the XL-80 system



LaserXL[™] software includes modules for linear, angular, rotary axis, flatness, straightness and squareness measurements, as well as dynamic measurement capability (see below). Users can select from English or a choice of several main languages* for LaserXL[™], QuickViewXL[™] and system manual.

Standard report options conform to many international machine performance checking standards, such as ISO, ASME, VDI, JIS and GB, and include a comprehensive Renishaw analysis.

The standard analysis software includes an option to generate compensation values for use in the CNC machine's controller, significantly improving the machine's positioning accuracy. Optional 'stand alone' linear error compensation packages include additional capability to read and write to the machine's controller, enabling existing error compensation parameters to be read and new ones to be uploaded.

Dynamic measurement

LaserXL[™] dynamic measurement facility allows the collection of data at rates of 10 Hz to 50 kHz (at 12 preset values) and provides displacement, velocity and acceleration data. There's even an integrated FFT package for frequency analysis.

For real-time 'oscilloscope style' display of live position velocity or acceleration data refer to QuickViewXL[™] software.

These dynamic measurements allow certain machine error characteristics to be highlighted and quantified. For example:

- · Pre-load and hysteresis of ballscrew and nut mechanisms
- · Positional stability and encoder performance
- Resonance characterisation of drive motors, spindles and other systems
- Feedrate accuracy, stability and interpolation accuracy
- Control-loop optimisation

Dual axis measurement

In some installations, one axis is controlled by two drives and two feedback systems (eg Spar mills, lathes and large dual beam type CMMs). In this instance, a second laser and optics, coupled with dual axis software, provides the capability to automatically capture data of parallel axes simultaneously.

Dual axis measurement software is included as standard with XL^{TM} software.



Typical dual axis set-up



QuickViewXL[™] software for live dynamic analysis

Live, real-time display of laser measurement data for linear displacement, velocity and acceleration analysis

QuickViewXL[™] is a simple to use, intuitive software package to capture, review and save dynamic data acquired via the XL-80 laser measurement system.

Knowledge of a position sensitive machine's dynamic characteristics - acceleration, velocity, vibration, settle time, resonance and damping - is critical in many applications. These characteristics will influence operational capabilities such as positional accuracy, repeatability, surface finish, throughput and wear.

QuickViewXL[™] provides the ideal tool for R&D, as it enables quick and easy investigation, review and characterisation of motion systems. It provides users with the following functionality:

- · Live data display in an oscilloscope style format
- Data capture rate of 50 kHz
- Supports measurement with linear, angular or straightness measurement optics
- Three modes of data capture: free running, single shot trigger and multi-shot trigger







- · Distance, velocity and acceleration display modes
- Selectable filters of 1, 2, 5, 10, 20, 50 and 100 ms response
- · Cursors for measurement of amplitude, time and frequency
- Manual scale, pan and zoom functions allowing 'close up' analysis of selected data
- · Auto scale option

Captured data can easily be loaded into supporting applications such as MathCAD, Mathmatica and Excel for further analysis using CSV file format. It can also be loaded into Renishaw's LaserXL[™] software allowing FFT analysis.

PC minimum requirements (Laser XL™ and QuickViewXL™)

Correct PC specification is vital for system performance. Please check with Renishaw for latest details.

- Processor 1 GHz Pentium, 512 MB RAM
- Drives CD-ROM for software installation
- Minimum screen resolution 1024 x 768, SVGA
- · Hard Disk 100 MB drive space needed for software installation
- Peripherals Keyboard and Microsoft mouse or compatible pointing device
- Operating system Windows[®] XP SP2/SP3, Windows Vista[™] or Windows[®] 7 (32 and 64 bit versions of these operating systems supported)
- Interface Recommended 3 free USB, 2 ports for XL laser, XC compensator and USB mouse. More USB ports may be required if an XR20-C, error compensation or dual functionality is required. Note: a USB hub can be used to increase the number of available USB ports.

System performance

Without reliable and accurate wavelength compensation errors of 20 ppm - 30 ppm would be common



±0.5 ppm	certified linear measurement accuracy over the full range of environmental operating conditions
1 nm	linear resolution (even at max. velocity)
4 m/s	maximum travel velocity
7 seconds	between each automatically updated environmental compensation
50 kHz	dynamic capture rate
80 m	linear range as standard

The greatest uncertainty in most laser measurements arises from variations in environmental conditions (air temperature, air pressure, humidity) compared to nominal values. Even small variations in conditions will alter the laser wavelength and the resulting measurement reading. For example, the following changes will increase laser wavelength by 0.25 ppm (parts per million):

- 0.26° C air temperature increase
- 0.93 mbar air pressure decrease

When variations of temperature, humidity and pressure from nominal values are combined they can cause 20-30 ppm uncertainty in measurement (even if the test conditions remain stable).

Renishaw uses it's XC-80 environmental compensation unit and very accurate environmental sensors to compensate for the effects on the laser wavelength.

Great effort has been taken to ensure Renishaw's XC-80 compensation system and sensors are accurate across the entire operating range of the system. It is this that maintains ± 0.5 ppm linear measurement accuracy from 0 °C - 40 °C (32°F - 104 °F) and over the full air pressure range (see graph comparisons with competitor system).



System linear measurement accuracy vs. environmental temperature



Material normalisation accuracy @ 10 ppm/°C



System benefits

Other factors for accuracy

- Laser frequency stabilisation ± 0.05 ppm over 1 year, ± 0.02 ppm over 1 hr is achieved by thermal control of the laser tubes length to within nanometres.
- Separate interferometer Renishaw uses a remote interferometer rather than one mounted on or inside the laser head, to avoid thermal drift.
- Accuracy for all measurements Laser linear measurement accuracy is only part of the metrology solution. You can also capture and analyse linear, angular, straightness, squareness, flatness and rotary axis motion with your XL-80 system, all using traceable linear measurement as a basis.

Measurement normalisation

To compensate for a machine's thermal expansion, the XC-80 unit can also receive data from up to three material temperature sensors. Placed in appropriate positions on the machine under test these normalise all readings to a reference temperature of 20 °C (68 °F). Thermal compensation is particularly important when performing linear measurements, especially on large machines or machines made of high expansion materials.

Accuracy by design

We believe that you should understand the background to our performance claims, to give you the confidence that the XL-80 delivers real accuracy where it counts, in day to day use.

Renishaw's accuracy specification is derived in accordance with recognised procedures for the calculation of measurement uncertainty (EA - 4/02) for laser stability, sensor output, and all key parameters and calculations affecting the final measurement. A summary of the error budget that is the basis of the published specification is available.

Overall system accuracy is quoted to the internationally recognised 95% confidence level (k=2) and includes allowance for drift in service.

Proven field performance

With an installed base of thousands of units worldwide operating over 18 years, our track record shows that Renishaw's laser systems continue to meet specifications day-in day-out, under a wide variety of conditions. This level of performance has been repeatedly verified by third party testing (including national laboratories).

Ease of use and set-up

Easy to transport, quick to set-up and use, the XL-80 allows users to reduce waiting time and increase available measurement time.

- Short preheat time (below six minutes)
- · Laser and stage designed for combined storage
- Stage features quick release tripod mounting



- Reduced components and connections. Both laser and compensator connect to your PC via USB; no separate interface, and no complicated set-ups are required
- The XC-80 compensator is powered via its USB connection, so no external power supply is needed

Flexibility and ease of operation

- 'Switchable' between standard (40 m) and long (80 m) range modes
- An analogue I/O port allows for analogue and quadrature signal outputs (factory specified option) and a trigger signal input
- · Easy to read LEDs for status and signal strength indication
- Uses standard or cordless mouse as trigger for remote manual data capture

The small size of the XL-80 laser and XC-80 compensator means that the whole system (less tripod) can now be packed into a truly portable 'wheelie-case'. A complete linear system in its case weighs around 12 kg. Even with the optional angular optics and accessories it weighs just over 15 kg; a highly portable system that others just can't match.

> Base system case takes full linear and angular system*





System 'wheelie-case' and additional tripod case are truly portable

* Optional larger case available for comprehensive optics and accessories storage



Total confidence

Quality in design, build and technical support are Renishaw hallmarks. That's vital, whether you're dealing in microinches or nanometres

Design



The XL system design is based on extensive feedback from laser and non-laser users to design out current system limitations and design in expected future requirements. The XL-80 is designed to allow updates and developments as user requirements change in the future.

The performance of Renishaw laser systems has been independently verified by the National Physical Laboratory (NPL), UK and Physikalisch-Technische Bundesanstalt (PTB), Germany.



Build

Renishaw's extensive manufacturing capabilities allow it to produce nearly all components and assemblies in its own factories.

It has an extensive and modern machine shop including surface finishing. There's even a complete PCB design, build and test facility.

This in-house manufacture, together with design, gives Renishaw the capability to fully understand and control the design and build process, unlike suppliers who outsource these activities.



Total confidence

Quality in depth

Renishaw plc is certified and audited regularly to ISO 9001:2008, the most recent ISO QA systems standard. This covers all aspects of design, manufacture, sales and after sales support, including our recalibration facilities.

The certificate is issued by BSI Management Systems, an internationally recognised certification body, accredited by UKAS.





ISO9001:2008 quality certificate

Test and certification

Product calibration of all laser systems is carried out by Renishaw and is traceable to the NPL (National Physical Laboratory) in the UK, using Renishaw's own certified iodine stabilised laser calibration system. Comprehensive calibration certificates are issued with all XL-80, XC-80 and XR20 systems giving test data in both tabular and graphical format, as well as full details of calibration standards used and of traceability to international standards.

Separate laser and sensor certification allows you to interchange components whilst maintaining traceable accuracy.

Product recalibration is available through your local Renishaw contact at facilities in the UK and USA (with NPL traceability), and Germany (with PTB traceability).

Image: State and the	
100 100 100 100	
100 30 10 10 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100	10
100 10	41 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10
Image: State	10 10 10 10 10 10 10 10 10 10 10 10 10 10 100 10 10 100 10 10 100 10 100 100
March 1997 March 1997 March 1997 March 1997 March 1997 March 1997 Ma	Image: Contract of the second secon
Total Contraction March Society March Society <thmarch< td=""><td>Total Total Note: Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status</td></thmarch<>	Total Total Note: Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status Note: Status
Same Yes Yes <thyes< th=""> <thyes< th=""></thyes<></thyes<>	Non-Street, IP Year Street, Street, parts, part
No. Sector 17.0 Million Marcola Million Marcola Million Marcola Million Millio	Hot Strategy KS, 40 History KS, 40 History KS, 40 Real Property KS, 40 Fill State 1 Real Property KS, 40 51 1 1 Real Property KS, 40 14 1 1 1
No Apparie and Commentation of Commentation and Apparies and Commentation of Commentation and Apparent	Non Importante del Inter- terra anti contenti del Inter- terra anti contenti del Interna del Interna Interna del Interna del I
National Constraint 1.0 5.000 National Constraints 1.0 2.000 National Constraints 1.0 2.000 National Constraints 2.00 2.00	Tests and Tests Test 10 100
registry of the second at 2	TRANSPORT TAXABLE FOR TAXABLE
THE REAL PROPERTY AND ADDRESS OF THE PROPERTY AND ADDRESS OF THE PROPERTY ADDR	and the second
	and a second sec
And the second to be address of the second s	
and the second se	televen menters. Mit for 1849 [Settion to Colombic case
the definition we also an also and the second of an and the	Millioner paralette Million (1949) Gereficate bis California auto- tetre californi auto- dition californi auto- dition (1949) - Million (1949)
Her Selfing Ser. Artistic W. Libertell Australia Teams content Artistic Content Artistic Content and Artistic Content and Artistic Content and Artistic Cont	Millioner speakers BYT for URUP Controls to Calibration and Intern defining their Lifetoners III Amount of the Internet speakers III Amount Official III Amount of the Internet speakers IIII III IIII IIII IIIII IIIIIIIIIII
All Annual Contract of the Con	Minister spreads Minister spr
All of the second sec	Ministre mention MPT to
terre contracte contracte and the second sec	Operating and the second sec
Anno administrator array and a second and a second administrator and a second administrator administ	Ministry memory MPT by second state Contained state Contained state MPT by second state <thm< td=""></thm<>
Diff (Fig.) Diff (Fig.) With (Fig.) United (Fig.) Diff (Fig.) <thdiff (fig.)<="" th=""> <thdiff (fig.)<="" th=""></thdiff></thdiff>	Advances interesting SPT No. BRIT Constraints to the Constraint of the Constraints of the Constraint of the Constraints of the Constraint of the Constraint of the Constraint of the Constraint of the Constraints of the Constraint of the Constraints of the Constraints of the Constraint of the Constraints of the Constraint of the Constraints of the Constrain
State States State States State States States	Ministry memory MPT No
Anti-Charles State Mill Links Mill Links Mill Links Mill State Mill State <th< td=""><td>Microsov menotomic Microsov menotomic M</td></th<>	Microsov menotomic Microsov menotomic M
An obtained an	Ministra meterini MP % MM # Permission Coloname Ministra meterini All Ministra
Mill Life Mill Life Mill Life Life Mill Mill Life Mill Mill Life Life Mill Mill Life Mill Mill Mill Three Mill Mill Life Mill Mill Mill Three Mill Mill Life Mill Mill Mill Three Mill Mill Life Mill Mill Mill Mill Three Mill Mill Life Mill	Microsov menomina Microsov menomina Microsov medicine (Marcine) Microsov medicine (Marcine) Microsov medicine Microsov medicine
An and a set of the se	An and a second se
All Film With Electromy Description and some All Film With Electromy Description and some Bits Film Bits Description Description and some Bits Film Bits Description	Bit operation Bit operation Bit operation Description
Alter California Control Alter Schlag, Schlagen auf der Schlagen aun	Ministry memory Mell Section 2010 (Control on Section 2010) (Control on Section 20
Mill Life With Life With Life Life Life Mill Life <t< td=""><td>Microsov menomic MPT too <thmpt th="" too<=""> MPT too <thmpt th="" too<=""></thmpt></thmpt></td></t<>	Microsov menomic MPT too MPT too <thmpt th="" too<=""> MPT too <thmpt th="" too<=""></thmpt></thmpt>
Annu Children or Segment under Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen bei Hannen Hannen bei Hannen bei	Ministry memory MPL % APR / Mo APP / MO
Alter Lange Mill Mill Littlement Alter Lange Mill	Ministration WT to definition MHT bits MHT bits Definition for this sector and the sector and provide the sector and provide the sector and
An object out Affairs an University Present	Millioner spectreth WT for (M29 Certificate In Collection Million (M21-0) 491 (Certificate In Collection (Million (M21-0) 491 (Certificate In Collection (Million (M21-0) 491 (Certificate In Collection (Million (M21-0) 491 (Certificate In Certificate In Certi
No. (Million See Second Second Se	Altriana persente Altriana del la constante del del la constante del la constante del del la constante del la constante del del la
Anno destructioner Anno anno anno anno anno anno anno anno	Advances provided Art Sec. (1999) Controls Sec. (2019) International Art Sec. (2019) Intern
An other set Affilia an Lincole Planet, the set of the	Advances payments Will for URAP Control to California and titles different start. Advances and advances and the start of the start of the start of the payment and the start of the start of the start of the start of the start of the start of the start of the start of the start of the start of the st
the defent set Affilia Set Lincoles Manual Set	Alternative paralette Alternative Alternat
the deliver and all all all all all all all all all al	Alternative
and the second s	televen products In State of S
and a second sec	Reference reporterts STT for 1849 Deptember Sale
and the second s	Antonios pantaria STT No. (AND Combuse to Colombic and
	Andrew managers Art and a further and the second se
and the second s	
and the Sector Sectors	
menter ant manna mai	NAME OF TAXABLE PORT OF TAXABLE PO
1001 10 500 1000 10 500 1000 10 500 1000 10 500 1000 10 500	Rent of Sector S
AD AD ADD Detro polit house: 10 0.00 March politic prime 10 0.00	10 0.00 10 0.00 10 0.00 10 0.00
Nati Separa yan di Laki Nati yang yang di Laki Nati yang yang di Laki Nati yang di Laki Nati yang di Laki	National System 21 220 International Conditional Conditiona Conditional Conditina
Max Tapping 47, 0 471 ki 200 Bit Tapping variety 2-0 5-00 Bit Tapping variety 1-0 5-00 Bit Tapping variety 1-0 5-00 Bit Tapping variety 1-1 5-00 Bit Tapping variety 1-1 5-00 Bit Tapping variety 1-1 5-00	Non-Transmitter Alternation Non-Transmitter 0.0 Non-Transmitter 1.0 Non-Transmitter 1.0 Non-Transmitter 1.0
No. Sector 17.0 Million Marcola Million Marcola Million Marcola Million Millio	How Street How Street How Street Read Property KTA, ID KE Schlade 1
Number Year (Mar) Year (Mar) Non-Year (Y, Y, M) CFL (Y, Y) Year (Mar) Non-Year (Y, Y, M) CFL (Y, Y) Year (Mar) Non-Year (Y, Y, M) CFL (Y, Y) Year (Y, Y) Non-Year (Y, Y) CFL (Y, Y) CFL (Y, Y) Non-Year (Y, Y) CFL (Y, Y) CFL (Y, Y)	Sector Yes Mag Own gam Max Support 0.1, 0 (1) 52, 0 (1) 52, 0 Max Support over 2 2, 00 Max Support over 10 2, 00 Max Support over 10 2, 00 Max Support over 10 2, 00
Same Same Street Same Street Same Street Street Same Street Street Same Street Street Same Street Street Same Street Street Same Street Stree	Non-Dispute Year diag Year ages Non-Dispute 73, 00 4111120 1111100 Non-Dispute 24 21 200 Non-Dispute 24 10 200 Non-Dispute 24 10 200 Non-Dispute 24 10 200
Tax A State (1) Texa State (1) Radio Marcing (1) State (1) Radio (1) State (1) State (1)	Total State March State March State Ten Strate of the State State State State State Ten Strate of the State State State State State State of the State State State State State State of the State State State State State State of the State State State State State State
Data Processes Banding Processes Processes Banding Processes Processes Processes Banding participants Bit Same Processes Proc	Data Section Name Section Section
III III III III Text Sciences	March March March Name March March March March March March
M M M M Transmotory Transmotory Transmotory Transmotory	No.
Image: Control of the second	Полоничная на продактичная на продактична По продактичная на продактичная на продактичная на продактичная на продактичная на продактичная на продактична По продактичная на продактичная на продактичная на продактичная на продактичная на продактичная на продактичная
Marcolarity Marcolarity Marcolarity Bandle Marcolarity Marcolarity	No.0 No.0 No.0
Mail Mail Mail Non Torick Statements Torick Statements	Image: Control of the second
10 10 10 10 10 10 10 10 10 10 <td>1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1</td>	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
10 10 10 10 10 10 10 10 10 10 <td>1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1</td>	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100	100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100
The Action of State of St	1 11 11 11 11 11 11 11 11 11 11 11 11 1
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Marcol Marcol Marcol Marcol <
10	1 1
100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100	1 1
10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10 10	10
1 11 11 11 11 11 11 11 11 11 11 11 11 1	1 1
Image: second	10 10<
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
Land Press of State P	
Lance to get an any set of a set o	
Land of uses of your langes of your langes Lange of the same o	Sector Sector Sector 1 1 1 1 1 1 1 1 1 1 1 1
Land of uses of your langes of your langes Lange of the same o	Sector Sector Sector 1 1 1 1 1 1 1 1 1 1 1 1
Land of uses of your langes of your langes Lange of the same o	Sector Sector 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Control (10) (10) (10) (10) (10) (10) (10) (10)	State of the sector of a call tags: Call tags of the sector of a call tags: Call tags of the sector of a call tags: Image: Sector of tags of the sector of tags o
Control of the second sec	Later of products of products Later of products of products 0 1 0
Control of the second sec	Contract of the sector of



Laser calibration



XL-80 laser system: main specifications

Laser head XL-80	
Dimensions (weight)	214 mm x 120 mm x 70 mm (1.85 kg)
Power supply	External, 90 V AC - 264 V AC, auto sensing
System measurement capability	Linear, angular (and rotary), flatness, straightness and squareness
Laser output	LASER RADIATION DO NOT STARE INTO BEAM CLASS 2 LASER PRODUCT 632.8mm MAX 1mW CW IEC/EN 60825-1 : 2007
Interface	Integral USB comms, no separate interface
TPin (trigger signal)	Yes
Quadrature signal output	Yes (factory option)
Analogue voltage output	Yes
Signal strength LEDs	Yes

Your XL laser is supplied as a kit including:

- XL laser unit (with standard shutter)
- USB cable

- Power supply and cables
- Aux I/O connector
- System manual (CD-ROM)

System performance	
Linear measurement range	80 m
Linear measurement	±0.5 ppm

0		
Linear measurement accuracy	±0.5 ppm	
Laser frequency accuracy	±0.05 ppm	
Resolution	1 nm	
Maximum travel velocity	4 m/s*	
Dynamic capture rate	10 Hz - 50 kHz**	
Preheat time	<6 minutes	
Specified accuracy range	0 °C - 40 °C	
Environmental sensors		
	Range	Accuracy
Material temperature	0 °C - 55 °C	±0.1 °C
Air temperature	0 °C - 40 °C	±0.2 °C
Air pressure	650 mbar - 1150 mbar	±1 mbar
Relative humidity (%)	0% - 95% non-condensing	±6% RH
* 1.6 m/s (80 nm quadrature); 0.2 m/s (10 nm quadrature) ** 20 MHz in quadrature mode		

Environmental compensator XC-80	Care and
Dimensions (weight)	135 mm x 58 mm x 52 mm (490 g)
Power supply	Powered via USB from PC
Internal sensors	Air pressure Relative humidity
Remote sensors	1 air temperature 1 - 3 material temperature
Interface	Integral USB comms, no separate interface

Your XC compensator is supplied as a kit including:

- XC compensator unit
- · Air temperature sensors kit
- Material temperature sensor kit
- USB cable
- System manual (CD-ROM)

System cases and tripod		A
	Case 1 (base system)	Case 2 (full system)
Case dimensions (L x H x D)	560 mm x 351 mm x 229 mm	560 mm x 455 mm x 265 mm
System weight*	12 kg -17 kg	16 kg - 25 kg
	Universal tripod	base
Dimensions folded with boss (weight)	Ø160 mm x 640 (3.9 kg)) mm
Working height range (to laser output beam)	Minimum: 540 mm Maximum: 1560 mm (column up)	
Tripod case	Armoured nylon bag**	
Case dimensions	670 mm x 170 mm x 170 mm	
 * System in case weight depends upon options specified Lower weights indicated are for: Case 1: Linear XL and XC system Case 2: Linear, angular and straightness XL and XC 		

system ** Rigid tripod case available as an option

Other	
Warranty	3 years (with 5 year option)
Certification	XL, XC, air and material temperature sensors. Certificates comply with requirements of ISO 17025.
Quality system	ISO 9001, BSI certified

Measurement optics

The XL-80 system uses the same range of optics as Renishaw's ML10 system, covering linear, angular (including rotary axes), straightness, squareness and flatness measurements. All measurements are interferometric and therefore use the traceable international standard wavelength of laser light.



Other systems which use electronic targets to measure pitch, yaw and straightness errors, often compromise measurement accuracy and stability.



For rotary axis measurements the XR20-W rotary axis calibrator is available. When used with the XL-80 system and angular optics, gives fully automatic calibration of axes, with ±1 arc sec accuracy.

Optics accessories

LS350 beam steerer

This unique patented optic provides easy angular adjustment of the laser beam in both horizontal and vertical planes, making laser alignment a simple one step process. The beam steerer speeds up linear, angular and straightness measurements, whether in-line or at 90°. The optic is also compatible with the linear/angular combination kit and swivel/ fixed turning mirrors. Clamping screws allow the beam steerer to be easily attached to measurement optics.



Specification	Metric	Imperial
Steering angle range	±35 mm/m	±2°
Axial range	0 m – 10 m	0 ft – 33 ft

Swivel mirror

This mirror can be used as an alignment aid for ANSI B5.54 diagonal measurements. It is also useful when measuring slant-bed lathes. Clamping screws allow the mirror to be easily attached to measurement optics.



Fixed turning mirror

This mirror reflects the laser beam through 90°. Like the swivel mirror, it can be attached to the measurement optics to aid optical set-up and is used primarily when there is restricted access to the required axis of measurement.



Measurement specifications

Linear





Specification	Metric	Imperial
Linear measurement range	0 m – 80 m	0 in – 3200 in
Measurement accuracy	±0.5 ppm (parts per million)	
(with XC-80 compensator)		
Resolution	0.001 µm	0.1 µin
For measurements over 40 m it is recommended to use the long range		
linear accessory kit.		
Performance specifications for linear (above) and other measurement		
modes are quoted to 95% confidence level ($k = 2$), and are valid across the		
full environmental operating range.		

Angular





Specification	Metric	Imperial	
Axial range	0 m - 15 m	0 in - 590 in	
Angular measurement range	±175 mm/m	±10°	
Angular accuracy	±0.2%* ±0.5 ±0.1M µm/m	±0.2%* ±0.1 ±0.007F arc sec	
Resolution 0.1 µm/m 0.01 arc sec			
Where M = measurement distance in metres; F = measurement distance in feet			
% = percentage of calculated angle			
the second se			

 * With high accuracy angular optics (± 0.6% with standard optics)

Rotary





Specification	Metric	Imperial
Angular target range	up to 25 revolutions	
Measurement accuracy (zero at 0°)	±5 μm/m	±1 arc sec
Max axis (<5° axis rotation)	Unlimited	
rotation speed (>5° axis rotation)	10 rpm	
Bluetooth range	Typically 5 - 10 metres	
Orientation	Any	

Flatness





Specification	Metric	Imperial	
Axial range	0 m - 15 m	0 in - 590 in	
Flatness measurement range	±1.5 mm	±0.06 in	
Accuracy	±0.6% ±0.02 M ² μm	±0.6% ±0.08 F ² μin	
Resolution	0.01 µm	1 µin	
Foot spacing	50 mm, 100 mm and 150 mm	2 in, 4 in and 6 in (approx)	
Where $M =$ length of the diagonal in metres; $F =$ length of the diagonal in feet;			

% = percentage of calculated flatness





Specifica	tion	Metric	Imperial
Axial range	(short range)	0.1 m - 4.0 m	4 in - 160 in
	(long range)	1 m - 30 m	40 in - 1200 in
Straightness	measurement range	±2.5 mm	±0.1 in
Accuracy	(short range)	±0.5% ±0.5 ±0.15 M ² μm	±0.5% ± 20 ±0.5 F ² μin
	(long range)‡	±2.5% ±5 ±0.015 M ² μm	±2.5% ±200 ±0.05 F ² μin
Resolution	(short range)	0.01 µm	1 µin
	(long range)	0.1 µm	10 µin

Where M = measurement distance in metres; F = measurement distance in feet;

% = percentage of displayed value

‡ subject to environmental conditions

Squareness





Specifica	ition	Metric	Imperial	
Range		±3/M mm/m	±2000/F arc sec	
Accuracy	(short range)	±0.5% ±2.5 ±0.8 M µm/m	±0.5% ±0.5 ±0.05 F arc sec	
	(long range)	±0.5% ±2.5 ±0.08 M µm/m	±2.5% ±0.5 ±0.005 F arc sec	
Resolution		0.01 µm/m	0.01 arc sec	
Where M = measurement distance in metres of the longest axis;				

F = measurement distance in feet; % = percentage of displayed value

Renishaw plc

New Mills, Wotton-under-Edge, Gloucestershire GL12 8JR United Kingdom

T +44 (0) 1453 524524 F +44 (0) 1453 524901 E uk@renishaw.com

www.renishaw.com



About Renishaw

Renishaw is an established world leader in engineering technologies, with a strong history of innovation in product development and manufacturing. Since its formation in 1973, the company has supplied leadingedge products that increase process productivity, improve product quality and deliver costeffective automation solutions.

A worldwide network of subsidiary companies and distributors provides exceptional service and support for its customers.

Products include:

- Dental CAD/CAM scanning and milling systems
- Encoder systems for high accuracy linear, angle and rotary position feedback
- · Laser and ballbar systems for performance measurement and calibration of machines
- Medical devices for neurosurgical applications
- Probe systems and software for job set-up, tool setting and inspection on CNC machine tools
- Raman spectroscopy systems for non-destructive material analysis
- Sensor systems and software for measurement on CMMs (co-ordinate measuring machines)
- Styli for CMM and machine tool probe applications

Renishaw worldwide

Australia

- T +61 3 9521 0922 E australia@renishaw.com

Austria

T +43 2236 379790 E austria@renishaw.com

Brazil

T +55 11 4195 2866 E brazil@renishaw.com

Canada

T +1 905 828 0104 E canada@renishaw.com

The People's Republic of China

- T +86 21 6180 6416 E china@renishaw.com

Czech Republic

T +420 548 216 553 E czech@renishaw.com

France

T +33 1 64 61 84 84 E france@renishaw.com

Germany

T +49 7127 9810 E germany@renishaw.com

Hong Kong

T +852 2753 0638 E hongkong@renishaw.com

Hungary

T +36 23 502 183 E hungary@renishaw.com

India

T +91 80 6623 6000 E india@renishaw.com

Israel

- T +972 4 953 6595
- E israel@renishaw.com

T +39 011 966 10 52 E italy@renishaw.com

Japan

Italv

- T +81 3 5366 5316
- E japan@renishaw.com

Malaysia

T +60 3 5361 4420 E malaysia@renishaw.com

The Netherlands T +31 76 543 11 00

E benelux@renishaw.com

Poland

T +48 22 577 11 80 E poland@renishaw.com

Russia

T +7 495 231 16 77 E russia@renishaw.com

Singapore

T +65 6897 5466 E singapore@renishaw.com

Slovenia

T +386 1 527 2100 E mail@rls.si

South Korea

- T +82 2 2108 2830
- E southkorea@renishaw.com

Spain

- T +34 93 663 34 20
- E spain@renishaw.com

Sweden

- T +46 8 584 90 880
- E sweden@renishaw.com

Switzerland

- T +41 55 415 50 60
- E switzerland@renishaw.com

Taiwan

- T +886 4 2473 3177
- E taiwan@renishaw.com

Thailand

T +66 2 746 9811 E thailand@renishaw.com

Turkey

T +90 216 380 92 40 E turkiye@renishaw.com

UK (Head Office)

T +44 1453 524524 E uk@renishaw.com

USA

T +1 847 286 9953 E usa@renishaw.com

For all other countries

- T +44 1453 524524
- E international@renishaw.com

©2007-2011 Renishaw plc. All rights reserved.

e to the best of our knowledge. Renishaw operates a policy of continual improvement

and receiver and in fight of damage product appendice and optimized on management management and the second management of the RENISHAW® and the probe emblem used in the RENISHAW log are registered trademarks of Renishaw plc in the UK and other countries.

apply innovation is a trademark of Renishaw plc. Windows® and Vista® are registered trademarks of Microsoft Corporation in the United States and other countries.